Step by step tutorial: of Primux Tech Ciclón 2 Quad core Audio connector

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.

Opening Tool for tablets, smartphones, laptops and other devices

4,34 €

Kit of tools profesional 70 in 1 - ARTICLE NUMBER: LSP031634

16,67 €

Pinza antiestática ESD redondeada

3,06 €

Step 1 - Primux Tech Ciclón 2 Quad core

Primux Tech Cyclone 2 Quad core
characteristics
Processor
Processor RK3188 Quad-Core (Cortex A9 + Mali400)
Ram memory: 1 GB
Storage
Internal: 8 GB
External: MicroSD up to 32 GB
screen
Size: 10.1 "
Type: Capacitive Multi Touch
Resolution: 1280x800
Battery
Battery 3.7V Polymer Lithium
OS
Android OS version 4.2 JB
Camera
Front and Rear
Connectivity
Wi-Fi 802.11 b / g / n
3G with external USB see models
MicroSD slot
HDMI output
Put USB

Before starting, make sure the tablet is off.

Step 2 - Back cover

The back cover is easily removed. We recommend the special opening tool, since it allows you to disassemble the lid without damaging it or scratching it.

Step 3

Go around the entire contour with this tool that resembles a "pizza cutter" and separate the back cover.

Step 4 - Audio connector

Remove the 2 Phillips screws that hold the audio connector module.

Disconnect the flex cable, by pulling on the tab of the connector and pulling gently.



Step 5

Finally, remove the audio connector.





E103A-PH
7.786.099
VER:03
PCB=0.6MM
GP
GND
MUTE
R
GND
J25

P15
FCF
FCF-3 94V-0
E232205