



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Elephone S8 Handset

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Heat-opening thermal mat, CPB320

69,61 €



Opening tool Smartphone, tablet

2,19 €



Pinza antiestática ESD redondeada

3,06 €



Set of professional tools for opening smartphones and tablets

18,97 €



Special SAT 0.75mm high friction PVC pick

1,07 €



Suction cup to separate screens in general

5,25 €



6-in-1 screwdriver, K-8107 with different heads, in blister

7,52 €



12.06 x 6.22 x 2.47 mm generic earpiece speaker

0,45 €

Step 1 - Remove back cover

We start by heating the back part at about 65 ° C for about a minute to soften the adhesive that holds the lid. When it is hot, we introduce an opening tool between it and the frame to take it off.





Step 2 - Remove intermediate housing

We took out the seventeen Phillips screws (PH # 00) that hold the intermediate housing and then pulled it off by prying it all the way around.





Step 3 - Disconnect components

Remove the two Phillips screws (PH # 00) that hold the plate shield and disconnect the components that are connected to it.





Step 4 - Removing the motherboard

Remove the two Phillips screws (PH # 00) that still hold the motherboard and also remove the SIM / SD tray. Now we can undo the base plate of the chassis.



Step 5 - Handset

All that remains is to take off the headset of the chassis.



