



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Wiko Robby Handset

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Set of 5 metal picks
for opening

3,09 €



Precision electric
screwdriver POL-QB-
3C

26,54 €



Opening tool
Smartphone, tablet

2,19 €



Terminal opening
tool, plastic

0,71 €



15.08 x 11.16 x 3.49
mm buzzer speaker
generic

0,92 €

Step 1 - Specifications

Dimensions: 79.1 x 155 x 10 mm

Weight : 185 g

SoC: Mediatek MT6580

Processor: ARM Cortex-47, 1300 MHz, Number of cores: 4

Graphic processor: ARM Mali-400 MP1, Number of cores: 1

RAM: 1 GB

Internal memory: 16 GB

Memory cards: microSD, microSDHC, microSDXC

Display: 5.5 in, IN, 720 x 1280 pixels, 24 bit

Battery: 2500 mAh, Li-Polymer (polymer lithium ion)

Operating Sitema: Android 6.0 Marshmallow

Camera: 3264 x 2448 pixels, 1920 x 1080 pixels, 30 fps

SIM card: Micro-SIM

Wi-Fi: b, g, n, Wi-Fi Hotspot

USB: 2.0, Micro USB

Bluetooth: 4.0

Location / Navigation: GPS, A-GPS



Step 2 - Back case

Using a plastic opening tool, we remove the back cover.



Step 3 - Battery

We extract the battery.





Step 4 - Cards

We extract all the cards that are in the phone.



Step 5 - Intermediate housing

We remove the 14 Phillips screws (PH # 00) and with a plastic opening tool, we uncouple all the edges of the intermediate casing.



Step 6 - Handset

Take off the handset that we are going to replace with the help of a metal pick.

