



**NadieMeLlamaGallina.com**

Porque Yo Lo Reparo

## Step by step tutorial: of Honor 20 Auxiliary board

For this tutorial you will need the following spared parts and tools that you cant get at our online store [Impextrom.com](http://Impextrom.com)  
Click on a tool for visit the website.



PREMIUM quality  
auxiliary boards with  
components for  
Huawei Honor 20

4,95 €



Heat-opening thermal  
mat, CPB320

69,61 €



BK-7275 (A Version)  
5 in 1 screwdriver

6,41 €



SIM card removal  
tool for all brands

1,61 €



Opening tool  
Smartphone, tablet

2,19 €



Pinza antiestática  
ESD redondeada

3,06 €



Set of professional  
tools for opening  
smartphones and  
tablets

18,97 €



Special SAT 0.75mm  
high friction PVC pick

1,07 €

### Step 1 - Back case

To begin with, we must apply heat to the back cover, and with a thin tool we will open a bit of a hole through which we can already introduce one or more plastic spikes, with which we will take off all the edges of the case taking care not to damage it.





## Step 2 - Intermediate housing

We remove the nineteen Phillips screws (PH # 00) that hold the intermediate housing, we will also use to remove the card tray, and with a thin tool we will unhook all the edges of the intermediate housing.





### Step 3 - We disconnect battery

We will disconnect the battery to work with greater security.



### Step 4 - Speaker

We take off the speaker with the help of a flat tool.



Step 5 - Auxiliary board

We disconnect the interconnection flex and the coaxial cable from the auxiliary plate, and using a flat tool we will detach the plate that we are going to replace.



