



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Acer One 10 Touch screen

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



Heat-opening thermal mat, CPB320

69,61 €



Pinza antiestática ESD redondeada

3,06 €



Set of professional tools for opening smartphones and tablets

18,97 €




Special SAT 0.75mm high friction PVC pick

1,07 €

Step 1 - Remove back cover

We start by removing the back cover. To do this, we will use a flat opening tool, which we will extend after the entire contour to separate it from the chassis.






Step 2 - Take off screen

We disconnect the flex from the display and from the touch screen. Then we heat the screen to about 60 ° C for about a minute. With the hot screen, we introduce a flat tool between this the frame to take it off.





Step 3 - Touch screen

To finish, we took off the flex from the touch screen of the chassis and removed it.

