



NadieMeLlamaGallina.com

Porque Yo Lo Reparo

Step by step tutorial: of Huawei P30 Pro Drums

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com
Click on a tool for visit the website.



HB486486ECW
battery for Huawei
P30 Pro (VOG-L29) /
Mate 20 Pro, LYA-

15,82 €



Heat-opening thermal
mat, CPB320

69,61 €



Opening tool
Smartphone, tablet

2,19 €



Set of professional
tools for opening
smartphones and
tablets

18,97 €



Special SAT 0.75mm
high friction PVC pick

1,07 €



Suction cup for
disassembling and
repairing

0,51 €



PREMIUM
screwdriver with 24
magnetic
replacement bits

10,41 €

Step 1 - Back case


To start we must apply heat to the back cover, and with the help of a fine tool and a suction cup we open enough space that allows us to introduce a plastic spike so as not to damage the back shell.






Step 2 - Intermediate housing with NFC antenna

We extract the ten Phillips screws (PH # 00) that hold the intermediate housing with the NFC antenna, and with the help of a flat tool we will disengage the intermediate housing.





Step 3 - We disconnected battery

Before starting to disassemble any component of the phone, disconnect the flex from the battery.



Step 4 - Lower housing



Remove the five Phillips screws (PH # 00) that hold the lower case and unhook it.



Step 5 - Interconnection Flex with charging connector

We disconnect and remove the interconnection flex.





Step 6 - Drums

To finish we will take off the battery that we are going to replace.



