Step by step tutorial: of Alcatel Pop 4 Rear camera

For this tutorial you will need the following spared parts and tools that you cant get at our online store Impextrom.com Click on a tool for visit the website.



Step 1 - Remove back cover and battery

First we remove the back cover. For this, we will leverage with the opening tool in the notch that brings with this purpose.

Then we remove the battery by lifting it with the help of the tool or directly with your hands.









WWW.NADIEMELLAMAGALLINA.COM 1 of 5









Step 2 - SIM and SD cards

We will not forget to remove the cards as it would be difficult for us to remove the intermediate casing.











Step 3 - Remove intermediate housing

Remove the screws indicated in the first image. Then, we will lever to release the housing from the notches that hold it.





WWW.NADIEMELLAMAGALLINA.COM











WWW.NADIEMELLAMAGALLINA.COM

It only remains to disconnect and remove the rear camera.











WWW.NADIEMELLAMAGALLINA.COM 5 of 5