## Step by step tutorial: of Ulefone Armor X5 Vibrator

For this tutorial you will need the following spared parts and tools that you cant get at our online store <a href="Impextrom.com">Impextrom.com</a> Click on a tool for visit the website.



## Step 1 - Warm screen

We apply heat with a thermal mat on the screen, with a metal tool we will open a small gap and introduce a plastic spike, with which we will take off all the edges until we can take them off all their contour.





WWW.NADIEMELLAMAGALLINA.COM 1 of 6










Step 2 - Fullscreen

Once the screen is separated, we will remove the Phillips screw (PH # 00) that holds the shield, we will remove it with an antistatic clamp and release the connector with the help of a plastic tool.





WWW.NADIEMELLAMAGALLINA.COM 2 of 6









Step 3 - Intermediate housing

Once the screen is separated, we remove the tray, and remove the eleven Phillips screws (PH # 00) that hold the intermediate housing.





WWW.NADIEMELLAMAGALLINA.COM 3 of 6













Once the intermediate housing of the terminal is separated, we disconnect the battery with the help of a plastic tool.





**Step 5 - Components** 

We disconnect the microphone from the auxiliary plate with the help of a thin plastic tool, then we will remove the three Phillips screws (PH # 00) that hold the plate to the chassis, and with the help of a thin plastic tool we lift the plate from a corner to remove it.

We lift the vibrator from its housing by prying it from its base, and disconnect the coaxial from the plate to be able to remove.









WWW.NADIEMELLAMAGALLINA.COM 5 of 6








Step 6 - Vibrator

Once we have the motherboard out, we can remove the vibrator using a tin soldering iron to separate it from the plate.





WWW.NADIEMELLAMAGALLINA.COM 6 of 6